



Säkerhetsventil 09160

Denna 7,0 bars säkerhetsventil är monterad på Isotemp Basic och Slim/B i produktion sedan senhösten 2006.

Vid tömning av beredaren, vrid vredet ett snäpp åt vänster (moturs) och ventilen står öppen. Vrid ytterligare ett snäpp åt vänster så stängs ventilen och är då i arbetsposition.

Vid tömning, glöm inte att luft måste tillåtas komma in upptill i beredaren.

Safety valve SFD00023AA

The 7.0 bar 100 psi safety/relief valve SFD00023AA is mounted on Isotemp Basic and Slim/B since late 2006 production.

Turn the knob one snap to the left to drain the tank. The valve will stay open until the knob is further turned a snap to the left.

Turn the knob further one step to the left and the valve will close again and it is now in its normal working position.

Please note, when draining the water heater, air must be allowed to enter in the top of the tank.

2007-01-10/LLG
Publ/Safety valve 09160

Thermoprodukter AB

Dragonvägen 6
SE-392 39 Kalmar
Sweden
Tel +46 480 425 887
E-mail: info@isotherm.se
www.isotherm.se



Indel Webasto Marine S.r.l.
Zona Artigianale sn
IT-61019 S. Agata Feltria (PU) - Italy
Tel: +39 0541 848030
E-mail: info@indelwebastomarine.com
www.indelwebastomarine.com